



Sun Hydraulics (China) Co., Ltd. Dongguan Branch

ADD: Room 302, Building 10, 38 Dongke Road, Dongcheng Street,  
Dongguan city, Guangdong Province

TEL: +86 (755) 26010708

Sales Tel: +86 (755) 26010859

Oversea sales: (+86) 13925211653

China sales: (+86) 13602627256

P.C.: 523127

WEB: [www.joyonway.com](http://www.joyonway.com)

After-sales service: [service@joyonway.com](mailto:service@joyonway.com)



Scan QR code with mobile device  
to download JOW SPA APP

# PB562

## Operation instruction

All features and functions available are described in this document.  
Your system display may vary.

Warning	01-02
Control Panel Specifications and Installation Instructions	03-06
Button description	07-08
Main interface introduction	09-10
Music	11
Lights	12-14
Setting instructions	15-25
1.1 How to enter the setting interface	15
1.2 Settings	15
1.2.1 Heat&Cool	16
1.2.2 Clim8zone	18
1.2.3 Filter	20
1.2.4 General	21
1.2.5 User Mode	24
1.2.6 Wifi	25
1.2.7 Overview	26
1.2.8 Information	26
Panel warning information	27-37

### WIFI:

Operating Frequency: 2012-2472MHz

Output Power: Max 20dBm

RF Hardware Version: xxx

RF Software Version: xxx

### EMF:

These devices comply with RF specifications when the device is used at 20 cm from your body.

### EMC:

These devices can be connected only to a supply with system impedance no more than 0.099 ohm for Single-phase input or 0.001 ohm for Multi-phase input. In case necessary, please consult your supply authority for system impedance information.

Importer: xxx

### RSS-Gen & RSS-247 statement:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### RSS-102 Statement:

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme à l'exposition aux rayonnements Industry Canada limites établies pour un environnement non contrôlé.

## Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC Caution:

Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

### FCC Statement:

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."


This controller is not intend for transportable pool use.

## Control Panel Specifications and Installation Instructions

2.4 inch TFT color display screen, 8 capacitive touch buttons




PB562 control panel design



Suggested hole size


## Control Panel Specifications and Installation Instructions



## Control Panel Specifications and Installation Instructions

### Control Panel Installation Instructions

1




Make a hole in the appropriate position of the hot tub according to the size of the control panel, and clean the surrounding area of the hole, especially burrs, debris, etc., to ensure that the control panel can stick on firmly.

2




As shown in the figure, remove the adhesive protective sticker from the control panel. Special attention: It is strictly prohibited to touch adhesive with hands; It is prohibited to have water or other impurities from touching the adhesive surface; Install the control panel onto the tub within 60 seconds after removing the adhesive sticker.

3



As shown in the figure, after removing the with the adhesive protective sticker, install the control panel at the cleaned hole.

4



As shown in the figure, after the control panel is installed, press the control panel tightly with hands for 60 seconds and push the control panel back and forth for 5-10 times.

### Warning

1. Please connect power by strictly following the SPA wiring diagram.
2. Please do not power on the SPA until the water level reaches the water level line inside the tub.

### Warning

Please set the date and time before using the SPA control system.



### Pump 1 shortcut button

If pump 1 is a single speed pump, it is used to control the on/off of pump 1; if pump 1 is a dual speed pump, press the button continuously to switch between low speed, high speed, or off. The specific sequence is as follows: low speed on ->high speed on ->off.



### Light shortcut button

There are two modes for the lights. In the on/off mode, press the button to turn the lights on and off. In RGB mode, press the button to turn the lights on and off, and control lights pattern in lights interface or set lights color in lights color interface. (The "on/off mode" or "RGB mode" has been determined at the factory and cannot be changed by the user)

## Button description



### Screen reverse button

Used to reverse the display content upside down 180 degrees, and the direction of the navigation buttons also changes accordingly.



### Multifunction button

Used for functions such as pump 2 (if equipped) or blower (if equipped) or user mode.



### Navigation (Up) button

Used to select functions upwards or adjust parameters upwards in the menu interface.



### Navigation (down) button

Used to select functions downwards, or adjust parameters downwards in the menu interface.



### Confirm button

Used to activate the cursor in the function area, change the function status, or enter the function page; In the menu interface, confirm or switch the function status.



### Set (Return) button

Used as quick access to the set interface, or to save and return when the function status changes.

## Main Interface introduction



Details are as follows

①		Current time.
②		The status of the functions in operation.
		Disinfecting running
		Heater running
		Heat pump cooling
		Heat pump heating
		WiFi not connected
		WiFi is connected
		NOR mode is running
		ECO mode is running



The circulating pump is running



BT is connected



Pack number: Displayed when multiple packs are connected at the same time



User mode in operation

3



Current water temperature  
°F/°C.

4



Preset water temperature °F/°C.

5



Function control area. Please press the button "○" to activate the cursor, then press the button "▼" or "▲" to move the cursor and select the corresponding function, and then press the button "○" to change the function status or enter the function interface.

The water pump will automatically shut down after running for 30 minutes.

The blower will automatically shut down after running for 30 minutes



Pump 1



Pump 2



Pump 3



Pump 4



Settings



Music



Blower



Light off



Light on

### Music connection




The music icon will appear and music function can be used only when the system is connected to a BT audio amplifier.

## Music connection steps :

- On the main interface, press the button "⊙" to activate the cursor, and then press "⬆" "⬇" to move the cursor to select the music icon, and then press the button "⊙" to enter this interface.
- Press the button "⬆" " or "⬇" to select the "🔌" function icon in the music interface, and then press the button "⊙" to turn on the BT function "🟢".
- Turn on the Bluetooth function on your mobile device, find the BT name with the prefix "JOYONWAY\_", press Connect, enter the PIN code: 2288, and connect.
- When the screen displays, "BT Connected", the BT connection is complete.
- Then, you can use the music software on your phone to play music. The control panel can synchronize the phone's operations of pause/play, previous/next song, and high/low volume.

NOTE: If you cannot connect BT, Please try clicking the button "⬆" or "⬇" in the music interface or Select the function icon "🔌" and press and hold the button for "⊙" 5 seconds to reset and try again.



Press the button "⬆" " or "⬇" to select the "🔌" function icon in the main interface, and then press the button "⊙" to enter the lights interface.

- Mode toggle button. Select the "Normal" button and press the "⊙" button to toggle "Normal"/"Water Temp." mode.
- Power button. It powers On/Off all User-Controlled lights. If the button icon has a white ring, at least some User-Controlled lights are powered On. If the button doesn't have a white ring, all User-Controlled lights are powered Off.
- Speed control for light patterns. The speed supports 0-2.
- Go to the color palette button.
- Color wheel light pattern. Displays the full color spectrum.
- Party light displays, in a flashy a festive pattern.
- Lounge light displays slow dimming soothing pattern.

In the Lights interface, use the up and down buttons "⬆" / "⬇" to switch between function icons, and use the OK button "⊙" to confirm the setup.

## Water Temperature color chat

- |              |  |               |   |
|--------------|--|---------------|---|
| <b>RED</b>   | Above 108°F.<br>Approximately 42.2°C.  | <b>ORANGE</b> | Between 2°F above the set temperature and 107°F.<br>Approximately 1°C above the set temperature and 41.6°C.       |
| <b>GREEN</b> | Within +/- 2°F of the set temperature.<br>Approximately within +/- 1°C of the set temperature. | <b>BLUE</b>   | Between 46°F and 2°F below the set temperature.<br>Approximately between 7.7°C and 1°C below the set temperature. |

**WHITE** Less than 45°F.  
 Approximately less than 7.2°C.

**PURPLE** Temperature unknown because the water has not been cycled.

## Color interface (RGB mode)

Custom colors

Confirm the Save button

Reset button  
(Reset to the settings before entering the current screen)

Color

Up button  
(You can choose colors from 359 - 0)

Down button  
(You can choose colors from 0 - 359)

Brightness adjustment slider

In the lights interface, Select the icon “”, and press the button “” to enter color interface.

In the color interface, use the up or down buttons “” / “” to switch the status of the ribbon, and use the OK button “” to switch to the next ribbon.

## 1.1 How to enter the setting interface



Press the button “” to enter the settings Interface and proceed with function settings.

## 1.2 Settings

Interface overview

- Heat&Cool
- Clim8zone
- Filter
- General
- User Mode
- Wifi
- Overview
- Information

Details are as follows

### 1 Heat&Cool



### 2 Clim8zone




## Setting instructions

3 Filter



4 General



5 User Mode



6 Wifi



7 Overview



8 Information

Jets	Speed
Jets 1	1 SPD
Jets 2	1 SPD
Jets 3	1 SPD
Jets 4	1 SPD

### 1.2.1 Settings / Heat&Cool

1

#### Heat&Cool



— (1) Temperature

— (2) Mode

— (3) Cycle Time

— (4) Unit

Interface overview

Details are as follows

## Setting instructions

### (1) Temperature



Change the current water temperature. Select the "Temperature" function and press the button "⊙" to enter this interface. By pressing the buttons "▲" or "▼" to adjust the temperature. After the adjustment is completed press the button "⊙" to return and save.

The temperature setting range is from 50 °F to 104 °F / 10 °C to 40 °C.

When the heating function is activated, this temperature value will be the operating target.

### (2) Mode



NOR: The heating/cooling is turned on all day long  
ECO: The heating/cooling is only turned on during Cycle Time.

### (3) Cycle Time



How to adjust the heating time period: First press the button "⊙" to select number "●". Then press the button "▲" or "▼" to activate or deactivate this time period. Then, press the button "⊙" to select the adjusted time period item (starting hours and minutes, ending hours and minutes), and press the button "▲" or "▼" to adjust the value. Finally, press the button "⊙" to return and save.

Set the daily heating operation time period as on or off.

- On: The heating will start running within the set time period everyday.
- Off: This time period does not the heating operation.
- Select the currently set time period.

### (4) Temperature Unit



Adjust the temperature unit. Select the "Temperature Unit", and press the button "⊙" to switch between °C/°F temperature units.

This setting changes how water temperature is displayed throughout the system.

### 1.2.2 Settings / Clim8zone

#### 2 Clim8zone (Display only when the system is equipped with a heat pump)



##### (1) Clim8zone



Details are as follows

Set the heat pump mode. Select "Clim8zone", press the button "  " to cycle through Disabled/Heat Only/Cool Only/Heat&Cool.

Disabled: The heat pump does not operate in any circumstances.

Heat Only: The heat pump only operates the heating function.

Cool Only: The heat pump only operates the cooling function.

Heat&Cool: The heat pump operates heating and cooling functions.

##### (2) Speed




Set the running speed of the heat pump, select the "Speed", and press button "  " to cycles through Low/High/Auto.

Low: Low speed, the heat pump only operates in low speed mode, consuming less energy.

High: High speed, the heat pump only operates in high-speed mode and can quickly reach the preset temperature.

Auto: Automatic, the heat pump automatically adjusts its operating speed according to the environment, taking into account energy consumption and quickly reaching the preset temperature.

#### (3) eHeater



Set the electric heating collaboration mode, select the "eHeater" function, press the button "  " to cycle through Continuous/EBOOST/Disable

Continuous: eHeater will continue to operate when heating is needed. (Clim8zone and eHeater operate simultaneously during heating)


eBOOST: eHeater will only be activated when there is a significant difference between the current temperature and the preset temperature. (During heating, the Clim8zone operates first)

Disabled: eHeater does not operate. (Only Clim8zone runs during heating)

If the "Clim8zone" mode is set to Disabled or Cool Only, the "eHeater" mode can only be Continuous.

If the "Clim8zone" mode is set to Heat Only or Heat&Cool, the "eHeater" mode can be set as Continuous/eBOOST/Disabled.

#### (4) Information



This interface displays temperature and software version information about the Clim8zone heat pump.

### 1.2.3 Settings / Filter

#### 3 Filter



Interface overview

Details are as follows

#### (1) Cycle Time



How to adjust the filtering time period: First press the button "⊙" to select number "●". Then press the button "▲" or "▼" to activate or deactivate this time period. Then, press the button "⊙" to select the adjusted time period item (starting hours and minutes, ending hours and minutes), and press the button "▲" or "▼" to adjust the value. Finally, press the button "⊙" to return and save.

Set the daily filtering running time period and its on and off.

- ✔ On: The heating will start running within the set time period everyday.
- Off: This time period has no effect on the heating operation.
- Select the currently set time period.

#### (2) Filter Life




On the Filter usage interface, select the "Filter Life", press the "▲" or "▼" button to adjust the service life, press and hold "⊙" to clear the number of days in use, and press the "⊙" button to return to the previous interface.

- 1 The number of days the filter has been used is displayed.
- 90 The preset usage days of the filter are displayed.

### 1.2.4 Settings / General

#### 4 General



Interface overview

Details are as follows


#### (1) Date&Time



Adjust the date and time. Select the "Date&Time", and press the button "⊙" to enter this interface, then press the button "⊙" to select the items to be adjusted, and finally press the button "▲" or "▼" to adjust the value.

Set the current time, day, month, and year, and the system time will be based on this.

### (2) Panel Lock



Automatic screen lock time adjustment. After selecting the "Panel Lock" function, press the button "⊙" to cycle through **☑** /30S/1M/3M.

- ☑** : Automatic screen lock turned off.
- 30S: When it reaches 30 seconds without operating on the system, the screen will be locked.
- 1M: When it reaches 1 minute without operating on the system, the screen will be locked.
- 3M: When it reaches 3 minute without operating on the system, the screen will be locked.

When the screen is locked, the screen brightness decreases and the "🔒" icon appears on the screen, and the buttons will not react to short presses.

Unlocking the screen: When the screen is locked, press any button to activate unlocking, press in sequence the buttons "⊙" and "⊙" to unlock.

### (3) Brightness



Screen brightness adjustment. Select "Brightness" and press the button "⊙" to enter this interface, and then press the button "⏴" or "⏵" to adjust the brightness and press the button "⊙" to return.

The screen brightness range is 1-16.

### (4) Language

Language change: select the "Language" function, and press the button "⊙" to enter this page. Choose the language by pressing the button "⏴" or "⏵". After selecting the language, press the button "⊙" to confirm. Then, press the button "⊙" to return to previous interface and the language chosen takes effect.

The system will display the interface in the corresponding language.



### (5) Voltage Display



Turn on or off the display of electrical parameters in the Overview interface. Select the "Voltage Display" function, and press the button "⊙" to switch between **☑** / **☒**

- ☑** : Display electrical parameters on the Overview interface.
- ☒** : Do not display electrical parameters on the Overview interface.

Select the "Voltage Display", and press the button "⊙" to pop up a window. Press the button "⏴" or "⏵" to select "☑", and then press the button "⊙" to complete the setup.



- ⏴** : Return
- ☑** : Voltage Display confirmation

### (6) Water Level (display only when the system is equipped with a water level sensor)



Enable or disable water level sensor. Select the "Water Level" function, and press the button "⊙" to switch between /

: Enable water level sensor, when no water system will stop running.

: Disable water level sensor.

### (7) Reset Setting



Reset: select the "Reset Setting" function, and press the button "⊙" to pop up a window. Press the button "⏴" or "⏵" to select "✔", and then press the button "⊙" to complete the reset.

: Return : Reset confirmation

The reset operation restores all settings to their factory default values.

## 1.2.5 Settings / User Mode

### 5 User Mode



Save and activate user mode: select "User Mode" and then press the button "⊙" to enter this interface. Then press the button "⏴" to select the save location, and then press the button "⊙" to save (simultaneously activated) After displaying the effect "📁 - 👤" or selecting a save location, press the button "⏵" to activate the data stored (when there is data stored at this location) .

Not saved, not activated

Saved, not activated

Saved, activated

The stored data includes temperature units, automatic locking time, screen brightness, heating cycle time, filtering cycle time, etc.

## 1.2.6 Settings / Wifi

### 6 Wifi



### WiFi connection steps:

1. Scan the QR code on the control panel (Settings->WiFi interface) or search for the "JOW SPA" APP on the APP store and download the app. Install the "JOW SPA" APP on your mobile device. Register and log on to the APP. Please enable your mobile device's location information and turn Bluetooth on, connect a WiFi signal.
2. In the WiFi interface (Settings->WiFi interface) of the control panel, press "⊙" button to switch to off "WiFi" OR EZ "WiFi EZ Pairing" status. In EZ status, in the APP, find the "Home" interface, press the "+" icon, and add a device.
3. Please follow the APP instructions to enable the related permissions. Then it will show a device on "JOW SPA" if this device is on pairing status, select the device to join the net. Follow the joining net step on "JOW SPA" .
4. When the device is added successfully, status will appear on the WiFi interface of the control panel "WiFi Connected", indicating that the connection is made.
5. Then, you can control your device on your mobile app "JOW SPA" through the internet.

### 1.2.7 Settings / Overview

#### 7 Overview



— Display current temperature



— Display current voltage



— Display current power



Display changes in temperature and power within 24 hours

### 1.2.8 Settings / Information

#### 8 Information

Information	
Jets 1	1 SPD
Jets 2	1 SPD
Jets 3	1 SPD
Jets 4	1 SPD
Lights	RGB
Lights V	5V
Blower	Yes
Disinfection	Yes
Cpump	Cpump
Power Limit	Off
WiFi Module	Yes
Panel ID	NQ1
Panel VER	Pb562 V10
Pack VER	P69b133 V10

Interface overview

In the "Information" interface, relevant information about the system is displayed.

When there are some states that require user attention in the control system, the control panel will display warning information of the state on the control panel. If there are several types of information that need to be displayed at the same time, these information will be loop displayed.

The following is the screen status when these information are displayed, as shown in the figure:



Warning message display location

When the following fault message appears, first try to power off the SPA and then power on again a few minutes later to clear the fault; If the fault occurs again, please follow the instructions below to handle the fault; During the troubleshooting process, ensure that the power connection to the SPA is disconnected.

**F1:Water temperature sensor is disconnected**

**Temperature sensor disconnected**

The control system has detected that the temperature sensor is not connected. Please check the temperature sensor and its connections, and replace it if necessary.

**F2:Water temperature sensor is short circuit**

**Temperature sensor short circuit**

The control system has detected a short circuit in the temperature sensor. Check the temperature sensor and its connections, and replace it if necessary.

## Panel warning information

---

### F3:Water temperature is too high

#### Water temperature too high

The control system has detected that the temperature of temperature sensor is too high.  
When the heater is started, if there is no water or water flow is small in the heating tube, this message may appear .  
Measure: Please ensure that there is sufficient water in the SPA and the heating circulation pipeline is unobstructed.

### F4:Water temperature is too low

#### Water temperature too low

The control system has detected that the temperature of the temperature sensor is too low.  
Please pay attention to frost protection.

### F5:EEPROM error

#### Memory Fault

When a memory fault occurs, please power off the SPA and power it back on after a few minutes. If the memory fault occurs again, contact the service provider or manufacturer.

### F6:Manual-reset thermal switch is open

#### Overheat protection switch (manual reset) on

If the overheat protection switch is turned on, there may be overheating in the heating tube. Please manually reset the overheat protection switch or contact the service provider and manufacturer.

### F9:System setting error

#### System settings error

Cause: The system configuration item read from the motherboard memory by the control system after power on was verified not correct.  
Action: Please turn off the power and wait for 10 seconds before powering on again. If this message appears again, please contact the service provider or manufacturer.

## Panel warning information

---

### F10:Communications error

#### Control panel and control pack cannot communicate

Cause:  
The control panel cannot exchange information with the control pack.  
Action:  
Please turn off the power, and check if the wiring connection between the control panel and the control pack is good and if the connectors are tightly connected. After confirmation, power on again. If this fault cannot be eliminated, please contact the service provider or manufacturer.

### F12:Heater PT temperature is too high

#### Heating tube protection temperature too high

The control system has detected that the surface temperature of the heating tube is too high.  
Measure: Please ensure that there is sufficient water in the SPA and the heating circulation pipeline is unobstructed

### F13:Heater PT temperature is too low

#### Heating tube protection temperature too low

The control system has detected that the surface temperature of the heating tube is too low.  
Please pay attention to frost protection.

### F14:Heater PT temperature sensor is disconnected

#### Heating tube protecting temperature sensor disconnected

The control system has detected that the heating tube protecting temperature sensor is not connected.  
Measure: Please check the heating tube protecting temperature sensor and its connection, and replace it if necessary.

### F15:Heater PT temperature sensor is short circuit

Heating tube protecting temperature sensor short circuit

The control system has detected a short circuit in the heating tube protecting temperature sensor.

Measure: check the heating tube protecting temperature sensor and its connection and replace it if necessary.

### F17:No water

The water level detector detects that there is no water in the tub

There is not enough water in the tub.

Measure: Fill the tub with water above the water line.

### F20:Controller fault

When a microelectronic malfunction occurs

Please power off the SPA and power it on again after a few minutes. If a microelectronic malfunction occurs again, contact the service provider or manufacturer.

### Heat Pump ER03: Water flow failure

Water flow failure

Cause:

1. The water flow switch fault.
2. Low water flow.
3. The inlet and outlet water are reversed.
4. There is air in the pipe.
5. The pipe blocked.

Action:

1. Check the water flow switch and replace it if it is faulty.
2. Check the water valve and the temperature difference between inlet and outlet water.
3. Whether the inlet and outlet water pipes are correctly connected.
4. Emptying water system.
5. Pipe cleaning.

### Heat Pump ER04: Winter anti-freezing

Winter anti-freezing

Cause:

The ambient temperature is lower than the antifreeze setting value.

Action:

Normal protection procedure.

### Heat Pump ER05: High pressure protection

High pressure protection

Cause:

1. Low water flow.
2. Pressure switch fault.
3. The fan motor unwork or the speed too low.
4. Overcharged the refrigerant.

Action:

1. Check whether the temperature difference between inlet and outlet water is too large, and whether the outlet water temperature is too high.
2. Use a multimeter to check whether the high voltage protection switch works.
3. Check the water flow of the water pump and the speed of the fan.
4. Refill the refrigerant.

### Heat Pump ER06: Low Pressure Failure

Low Pressure Failure

Cause:

1. The evaporator fin is dirty and blocked.
2. Refrigerant leakage and dirty fin clogging lead to poor defrosting.

Action:

1. Clean the evaporator fins.
2. Find the leak point and weld it well, and then refill the refrigerant.

### Heat Pump ER09: Communication with the upper computer failed

Communication with the upper computer failed (Communication with Balboa system failed)

Cause:

1. The communication cable is in bad contact or damaged.
2. The mainboard and control panel are damaged.

Action:

1. Check and replace the communication cable.
2. Replace the mainboard and control panel.

### Heat Pump ER10: Communication fault of frequency conversion module

Communication fault of frequency conversion module (alarm when communication is disconnected between external board and drive board)

Cause:

1. The mainboard or driver board damaged.
2. The connector of the communication cable between the mainboard and the driver board is in poor contact or falls off.
3. The communication cable is damaged.

Action:

1. Replace the main board or driver board.
2. Check the communication cables between the main board and driver board.
3. Replace the communication cable.

### Heat Pump ER12: Exhaust too high protection

Exhaust too high protection

Cause:

1. Less refrigerant or leakage.
2. The system blocked.
3. Compressor refrigerant oil is insufficient.
4. The resistance value of the exhaust probe is offset, and the inlet temperature probe is dropped.

Action:

1. Refill the refrigerant.
2. Replace the filter.
3. Add refrigerant oil to the compressor.
4. Replace the exhaust probe and reconnect the water.
5. inlet temperature probe.

### Heat Pump ER15: Inlet water temp. Error

Inlet water temp. Error

Cause:

The sensor plug is in poor contact or off, or the sensor is damaged.

Action:

Check and replace the water inlet temperature sensor(T2 sensor).

### Heat Pump ER16: Outer coil pipe temp. Error

Outer coil pipe temp. Error

Cause:

The sensor plug is in poor contact or off, or the sensor is damaged.

Action:

Check and replace the coil pipe temperature sensor(T3).

### Heat Pump ER18: Exhaust gas temp. Error

Exhaust gas temp. Error

Cause:

The sensor plug is in poor contact or off, or the sensor is damaged.

Action:

Check and replace the exhaust gas temperature sensor(T1).

### Heat Pump ER19:

DC Fan Motor Failure

Cause:

The DC fan is damaged, the plug is in poor contact, or the plug is off.

Action:

1. Replace the DC fan.
2. Reconnect cables to the DC fan.

### Heat Pump ER20: Abnormal protection of frequency conversion module

Abnormal protection of frequency conversion module

Cause:

IPM module internal fault, check related problems according to the attached table.

Action:

Internal fault of IPM module, see attached table to check related problems.

## Panel warning information

### Heat Pump ER21: Ambient temp. Error

#### Ambient temp. Error

Cause:  
The sensor plug is in poor contact or off, or the sensor is damaged.  
Action:  
Check and replace the ambient temperature sensor(T4).

### Heat Pump ER23: Cooling outlet water temp. supercooling protection

#### Cooling outlet water temperature low protection

Cause:  
1. The water outlet temperature is lower than the system protection value, the water flow is small, and the pump is abnormal.  
2. The pipe has air or is blocked.  
3. The inlet water temperature probe is off.  
Action:  
1. Check whether the water valve or water pump is started.  
2. Clean the pipes and exhaust the air in the pipes.  
3. Reconnect the water outlet temperature probe.

### Heat Pump ER27: Outlet temperature fault

#### Outlet temperature fault

Cause:  
The sensor plug is in poor contact or off, or the sensor is damaged.  
Action:  
Check and replace the water outlet temperature sensor(T6).

### Heat Pump ER29: Return gas temp. Error

#### Return gas temp. Error

Cause:  
The sensor plug is in poor contact or off, or the sensor is damaged.  
Action:  
Check and replace the suction gas sensor(T5).

### Heat Pump ER32: Heating outlet water high temperature protection

#### Heating outlet water high temperature protection

Cause:  
1. The water outlet temperature is higher than the system protection value, the water flow is small, and the pump is abnormal.  
2. The pipe has air or is blocked.  
3. The inlet water temperature probe is off.  
Action:  
1. Check whether the water valve or water pump is started.  
2. Clean the pipes and exhaust the air in the system.  
3. Reconnect the water outlet temperature probe.

## Panel warning information

### Heat Pump ER33: Outer Door Coil High Temperature Protection

#### Outer Door Coil High Temperature Protection

Cause:  
The condenser Temp. is higher than the protection setting point, usually appeared with Er32, Priority display Er32.  
Action:  
solution like the E32.

### Heat Pump ER35: Compressor Current Protection

#### Compressor Current Protection

Cause:  
1. The incoming voltage supply is too low.  
2. The compressor is overloaded.  
3. The thermal relay is damaged.  
Action:  
1. Ensure the incoming voltage supply is normal.  
2. Reduce compressor load, if damage, replace it.  
3. Replace the thermal relay.

### Heat Pump ER42: Internal Coil Temperature Failure

#### Internal Coil Temperature Failure

Cause:  
The sensor plug is in bad contact or falls off, and the sensor is damaged.  
Action:  
Check and replace the inner coil temperature sensor.

### Heat Pump ER44: Ambient Temperature Too Low Protection

#### Ambient Temperature Too Low Protection

Cause:  
The ambient temperature is too low.  
Action: /

### Heat Pump I-45: Ambient Temperature Too High Protection

#### Ambient Temperature Too High Protection

Cause:  
The ambient temperature is too high.  
Action: /

## Panel warning information

ER20 fault will display the following error codes at the same time, the error codes will switch every 3 seconds. Among them, error codes 1-128 are displayed in priority.

When error codes 1-128 don't appear, then error codes 257-384 can show.

If two or more error codes appear at the same time, then display error codes accumulation.

For example, 16 and 32 occur at the same time, display 48.

Error Code	Name	Description	Solution suggestion
1	IPM Over-current	1.The IPM overloaded or overheated. 2.The U,V,W driver short-circuited. 3.The IPM module fault. 4.The compressor damaged.	1.Ensure that the ring temperature, water temperature, water flow, etc. are within the operating range of the unit. 2.Use a multimeter to measure the motor U,V,W in ohmic gear to ensure no short circuit. 3.Replace the frequency conversion module. 4.Replace the compressor.
2	compressor synchronous abnormal	1.The compressor overloaded, instantaneously. 2.The compressor does not match the program. 3.The difference between high and low pressure starts the compressor excessively.	1.Ensure that the ring temperature, water temperature, water flow, etc. are within the operating range of the unit. 2.Replace the driver board with the correct program. 3.Ensure that the high and low pressure difference starts normally.
8	compressor output phase absent	1.The U, V, and W cables of the compressor are missing or improperly connected. 2.The compressor does not match the program. 3.The difference between high and low pressure starts the compressor excessively.	1.Check whether the U, V, and W wires of the compressor are missing or in poor contact. 2.Update the driver. 3.Ensure that the high and low pressure difference starts normally.
16	DC bus low voltage	1.The power supply voltage too high. 2.The capacitor fault. 3.The PFC module fault.	1.Ensure that the power supply is stable. 2.Check the capacitor after it is powered off. 3.Replace the faulty frequency conversion module.
32	DC bus high voltage	1. The fan on the host is faulty. 2. The air duct is blocked.	1.Ensure that the power supply voltage is normal. 2.Replace the capacitor. 3.Replace the faulty frequency conversion module.

## Panel warning information

64	Radiator over temperature	1.The fan on the host is faulty. 2.The air duct is blocked.	1.Check and replace the fan. 2.Ensure proper ventilation.
128	Radiator temperature error	1.The heat sink sensor is short-circuited or open. 2.Heat sink fouling. 3.The ambient temperature too high.	1.Replace the frequency conversion module. 2.Remove dust and scale from the heat sink. 3.Lower the ambient temperature.
257	communication failure	1.The connector of the communication cable between the main board and the driver board is in poor contact or falls off. 2.Internal components of the heat pump damaged. 3. The output voltage of the power supply board in the module abnormal or no output.	1.Reconnect and ensure stability. 2.Replace the internal components. 3.Replace the power module.
264	AC Input low voltage	1.The input voltage too low. 2.The current transformer damaged during transportation.	1.Ensure that the input voltage is normal. 2.Ensure that the current transformer works properly.
288	IPM too high temperature	1.The fan is faulty or the air duct blocked. 2.The ring temperature rises too fast, resulting in over-temperature drop too late to react. 3.The power supply voltage and current too high or too low.	1.Replace the fan. 2.Ensure that the air duct unblocked. 3.Reduce the ring temperature. 4.Ensure that the power supply voltage and current are normal.
320	Compressor peak current too high	1.Compressor load is too large. 2.The driver board is faulty. 3.The compressor is damaged.	1.Ensure that the ring temperature, water temperature, water flow, etc. are within the operating range of the unit. 2.Replace the compressor driver plate. 3.Replace the compressor.