

For Internal Installation of the Triflo Spa Bath pump, Edgetec recommends a drain tray and drain be fitted to collect any small water drip and divert to waste drain.

STANDARD INDOOR INSTALLATION



Pump and drain tray Installed with Drain Tube

STANDARD INDOOR INSTALLATION – AIR BLEED ACTIVATED



Pump and drain tray installed with drain tube and air bleed drain tube. (Air Bleed activated - see manual).

Pro-Tec Drain Tray



INSTALLATION

1. Drill out one drain port
2. (If Air bleed is activated, drill out the second drain port)
3. Position Triflo Pump to correct height and alignment – Allow 14 mm height for Drain Tray
4. Position Drain Tray beneath pump and fix to your mounting platform.
5. Install Drain Tray Horizontal
6. Connect pipework – ensure pump height and alignment do not apply loading to pipework
7. Fit the fixing screw to secure pump foot to Drain Tray – self-tapping #8G X 30 (supplied)
8. Connect one Drain tray port to waste drain
9. Connect Air Bleed tube to one of the Drain Tray ports. (Only when Air Bleed is activated)

Recommended tube is 10 mm ID flexible PVC