

SW	Setting	OFF	ON	Notes	SV2 / SV4 Models
1	Circ Fitted	Not Fitted	Fitted		
2	Pump 1 Type	Single Speed	Two Speed	If set to 'OFF' pump2 assumed fitted	
3	Pump 3 Type	Single Speed	Two Speed	Not used on SV2/SV2-VH models	
4	Pump 4 Fitted	Not Fitted	Fitted	Not used on SV2/SV2-VH models	
5	Phase Selection	Single Phase	2/3 Phase	If set to 'ON' dip switch 6 is enabled	
6	Multi Phase	Two Phase	Three Phase		

SW	Setting	OFF	ON	Notes	SV3 Models
1	Circ Fitted	Not Fitted	Fitted		
2	Pump 1 Type	Single Speed	Two Speed	If set to 'OFF' pump2 assumed fitted	
3	Pump 3 Fitted	Not Fitted	Fitted		
4	Not Used	-	-		
5	Phase Selection	Single Phase	2/3 Phase	If set to 'ON' dip switch 6 is enabled	
6	Multi Phase	Two Phase	Three Phase		